



MicroFire Cable Box (MFCB) User Guide



1. A Decal, Camera Knob, Key, Bracket Knob, and Camera Mounting Bracket are included with the MFCB.




2. Attach the Camera Mounting Bracket to the bottom of the MicroFire Camera using the Round Camera Knob.



3. Mount the camera with bracket inside the cable box using the 3 sided bracket knob.



4. Push the stake on the bottom half of the cable box into the ground. (see Warning below)



5. To close the cable box, line up the small plastic tab (A) between the top and bottom half, as well as the padlock loop (B) on the top half.

Once aligned, push down on the top. You will hear an audible click when the cable box is locked.



Optional: Apply the included Decal to help disguise the camera. Be sure to push down around the opening for the camera.

Once applied, use a sharp blade to cut the decal away from the opening.



Mounting Options

1. Use a "Duckbill Anchor" to secure the MFCB.
2. Cement the mounting stake in the ground.
3. Create a cement block on the bottom of the stake and bury the cement block when dry.

Warning!!

Never pound the cable box into the ground using the top of the mounting stake. You will damage the cable box.

